



INSTALLATION INSTRUCTIONS FOR STR-5BN08-50-00 DEFLECTORS V-STAR CLASSIC



Please read and understand these instructions completely before installation to avoid any possible injury to yourself or damage to your **V-STAR** and/or accessory.

DEALER:

These instructions contain important information for future reference and must be given to the customer.

TOOLS REQUIRED:

- 1 - 5mm Hex Key Wrench
- 1 - 12mm Wrench

PREPARATION:

Note: Cover the Fuel Tank and Front Fender to protect from damage.

1. Remove the Windshield Assembly from the Windshield Stays.

INSTALLATION:

1. Mount the Deflectors:

- A. Remove the Bolt from the Windshield Stay Assembly (Inset) that connects the Stay (6) to the Lower Rod. Store the Bolt, it will not be reused .
- B. Position the appropriate Deflector (1) at the Windshield Stay.
- C. Thread Bolt (4) through the lowest hole in the Deflector, through a Spacer (3), through the Windshield Stay (6), and into the Lower Rod.
- D. Repeat on the other side.
- E. Reinstall the Windshield Assembly with the Windshield Vertical Brackets outside the Deflectors. The Bolt will pass through the Washers, Windshield Vertical Brackets, then the Deflectors, and into the Windshield Stay.
- F. Adjust the Deflectors so they are parallel to the center of the Fork Tubes.

NOTE: Make sure rubber cushion contacts fork leg.

- G. Tighten the six Bolts to 23 Nm (17 ft-lb.) Torque.

2. MAINTENANCE:

Periodically check Bolts for tightness and re-torque. Clean using soft cloth and a non-abrasive metal polish.

3. CUSTOMER SERVICE:

For further information see your Yamaha Dealer.

PARTS LIST: Some parts listed are for reference purposes only.

ITEM	PART NAME	DESCRIPTION	QTY.
1	Deflector, Left		1
2	Deflector, Right (not shown)		1
3	Spacer		2
4	Bolts	M8-1.25 x 25,	2
5	Windshield		Ref.
6	Windshield Stay		Ref.

